


NO. 0887 CORE thermal jacket | women



Description (measured in cm)	S	M	L	XL	2XL	3XL
A: ½ Chest width	49	52	56	60	64	68
E: Front length from high point shoulder	66	68	70	72	74	76
H: Shoulder to shoulder	38.5	40	42	44	46	48
K: Sleeve length - long	65	66	67	68	69	70
L: ½ upper arm width	19	20	21	22.5	24	25.5

How to measure



Tolerance +/- in cm

A	E	H	K	L
1.5	1.5	1.5	1.5	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not