
NO. 0911 CORE stretch pants | women



Description (measured in cm)	S	м	L	XL	2XL	3XL	4XL
BB: ½ waist - relaxed	34	36.5	39.5	42.5	46.5	50.5	54.5
DD: ½ hip	49	51.5	54.5	57.5	60.5	63.5	67
EE: Inseam - long	80	80	80	80	80	80	80

How to measure

Tolerance +/- in cm



The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not