


NO. 0896 Padded jacket | stretch



Description (measured in cm)	S	M	L	XL	2XL	3XL	4XL	5XL	6XL
A: ½ Chest width	53	56	59	62	65	68	71	74	77
E: Front length from high point shoulder	66	68	70	72	74	76	78	80	82
H: Shoulder to shoulder	45	46.5	48	49.5	51	52.5	54	55.5	57
K: Sleeve length - long	69	70	71	72	73	74	75	76	77
L: ½ upper arm width	22	23	24	25	26	27	28	29	30

How to measure



Tolerance +/- in cm

A	E	H	K	L
1.5	1.5	1.5	1.5	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not