


# NO. 0875 Soft shell jacket | basic



Description (measured in cm)	XS	S	M	L	XL	2XL	3XL
A: ½ Chest width	51	53	55	58	61	64	67
E: Front length from high point shoulder	67	69	71	73	75	77	79
H: Shoulder to shoulder	45	46	47	48.5	50	51.5	53
K: Sleeve length - long	66	67	68	69	70	71	72
L: ½ upper arm width	20.5	21.25	22	23	24	25	26

## How to measure



## Tolerance +/- in cm

A	E	H	K	L
1.5	1.5	1.5	1.5	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not