


# NO. 0900 Thermal vest | classic



Description (measured in cm)	S	M	L	XL	2XL	3XL	4XL
A: ½ Chest width	54	57	60	63	66	69	72
E: Front length from high point shoulder	67	69	71	73	75	77	79
H: Shoulder to shoulder	44	45.5	47	48.5	50	51.5	53

## How to measure



## Tolerance +/- in cm

A	E	H	K	L
1.5	1.5	1.5	1.5	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not